Recommended Announcements



Effective Date: June 1, 2025

Front or Rear Differential Transmission 4X4 Funitation	Upper Engine Noise Timing Chain Issue or Noise Engine Smoking From Exhaust Check Engine Light Engine Wont Stay Running Oil Leak Head Gasket Leak Undetermined Engine Problem Other Engine Components Differential Noise cessive Play/ Slack in the Differential Transmission Slipping Transmission Shudder Acceleration Shudder Delayed/ Harsh Engagement Transmission Inoperable Specific Gears 4X4 Not Engaging/ Disengaging HUB Locking Problem 4X4 & 4WD Warning Light O2 Sensor Codes	Lower Engine Noise Turbo Codes Misfire Codes Cam and Crankshaft Position Codes Engine Overheating Engine Running Rough Engine Running Rough Engine Running Rough Engine Misfire Turbo Leak Sludge Cam Phasers Differential Locking or Binding Differential Leak Rear Differential Abnormal/ Hard Shifting Transmission Leaks Transmission Whining Torque Converter Problem Reverse Not Engaging Not Functioning Transfer Case Overheating Binding In 4 x 4 Transfer Case Leaking Failed/Inoperable Catalytic Converter	Engine Problem Yellow Light Required Differential Problem Yellow Light Required Transmission Problem Yellow Light Required 4X4 System Problem Yellow Light Required	Exempts Engine from Arbitration Exempts Differential from Arbitration Exempts Transmission fro Arbitration Exempts 4X4 fro Arbitration
Front or Rear Differential Transmission 4X4	Engine Smoking From Exhaust Check Engine Light Engine Knock or Tick Engine Wont Stay Running Oil Leak Head Gasket Leak Undetermined Engine Problem Other Engine Components Differential Noise cessive Play/ Slack in the Differential Front Differential Transmission Slipping Transmission Sludder Acceleration Shudder Delayed/ Harsh Engagement Transmission Inoperable Specific Gears 4X4 Not Engaging/ Disengaging HUB Locking Problem 4X4 & 4WD Warning Light O2 Sensor Codes	Misfire Codes Cam and Crankshaft Position Codes Engine Overheating Engine Running Rough Engine Running Rough Engine Running Rough Engine Misfire Turbo Leak Sludge Cam Phasers Differential Locking or Binding Differential Locking or Binding Differential Leak Rear Differential Abnormal/ Hard Shifting Transmission Leaks Transmission Whining Torque Converter Problem Reverse Not Engaging Not Functioning Transfer Case Overheating Binding In 4 x 4 Transfer Case Leaking	Yellow Light Required Differential Problem Yellow Light Required Transmission Problem Yellow Light Required 4X4 System Problem Yellow Light Required	from Arbitration Exempts Differential from Arbitration Exempts Transmission fro Arbitration
Front or Rear Differential Transmission 4X4	Check Engine Light Engine Knock or Tick Engine Wont Stay Running Oil Leak Head Gasket Leak Undetermined Engine Problem Other Engine Components Differential Noise cessive Play/ Slack in the Differential Front Differential Transmission Slipping Transmission Shudder Acceleration Shudder Delayed/ Harsh Engagement Transmission Inoperable Specific Gears 4X4 Not Engaging/ Disengaging HUB Locking Problem 4X4 & 4WD Warning Light O2 Sensor Codes	Cam and Crankshaft Position Codes Engine Overheating Engine Running Rough Engine Misfire Turbo Leak Sludge Cam Phasers Differential Locking or Binding Differential Leak Rear Differential Abnormal/ Hard Shifting Transmission Leaks Transmission Leaks Transmission Whining Torque Converter Problem Reverse Not Engaging Not Functioning Transfer Case Overheating Binding In 4 x 4 Transfer Case Leaking	Yellow Light Required Differential Problem Yellow Light Required Transmission Problem Yellow Light Required 4X4 System Problem Yellow Light Required	from Arbitration Exempts Differential from Arbitration Exempts Transmission fro Arbitration
Front or Rear Differential Transmission 4X4	Engine Knock or Tick Engine Wont Stay Running Oil Leak Head Gasket Leak Undetermined Engine Problem Other Engine Components Differential Noise cessive Play/ Slack in the Differential Front Differential Transmission Slipping Transmission Shudder Acceleration Shudder Delayed/ Harsh Engagement Transmission Inoperable Specific Gears 4X4 Not Engaging/ Disengaging HUB Locking Problem 4X4 & 4WD Warning Light O2 Sensor Codes	Engine Overheating Engine Running Rough Engine Misfire Turbo Leak Sludge Cam Phasers Differential Locking or Binding Differential Leak Rear Differential Abnormal/ Hard Shifting Transmission Leaks Transmission Whining Torque Converter Problem Reverse Not Engaging Not Functioning Transfer Case Overheating Binding In 4 x 4 Transfer Case Leaking	Yellow Light Required Differential Problem Yellow Light Required Transmission Problem Yellow Light Required 4X4 System Problem Yellow Light Required	from Arbitration Exempts Differential from Arbitration Exempts Transmission from Arbitration
Front or Rear Differential Transmission 4X4	Engine Wont Stay Running Oil Leak Head Gasket Leak Undetermined Engine Problem Other Engine Components Differential Noise cessive Play/ Slack in the Differential Front Differential Transmission Slipping Transmission Shudder Acceleration Shudder Delayed/ Harsh Engagement Transmission Inoperable Specific Gears 4X4 Not Engaging/ Disengaging HUB Locking Problem 4X4 & 4WD Warning Light O2 Sensor Codes	Engine Running Rough Engine Misfire Turbo Leak Sludge Cam Phasers Differential Locking or Binding Differential Leak Rear Differential Abnormal/ Hard Shifting Transmission Leaks Transmission Whining Torque Converter Problem Reverse Not Engaging Not Functioning Transfer Case Overheating Binding In 4 x 4 Transfer Case Leaking	Yellow Light Required Differential Problem Yellow Light Required Transmission Problem Yellow Light Required 4X4 System Problem Yellow Light Required	from Arbitration Exempts Differential from Arbitration Exempts Transmission from Arbitration
Front or Rear Differential Transmission 4X4	Oil Leak Head Gasket Leak Undetermined Engine Problem Other Engine Components Differential Noise cessive Play/ Slack in the Differential Front Differential Transmission Slipping Transmission Shudder Acceleration Shudder Delayed/ Harsh Engagement Transmission Inoperable Specific Gears 4X4 Not Engaging/ Disengaging HUB Locking Problem 4X4 & 4WD Warning Light O2 Sensor Codes	Engine Misfire Turbo Leak Sludge Cam Phasers Differential Locking or Binding Differential Locking or Binding Differential Locking or Binding Mathematical Differential Leak Rear Differential Abnormal/ Hard Shifting Transmission Leaks Transmission Whining Torque Converter Problem Reverse Not Engaging Not Functioning Transfer Case Overheating Binding In 4 x 4 Transfer Case Leaking	Differential Problem Yellow Light Required Transmission Problem Yellow Light Required 4X4 System Problem Yellow Light Required	Exempts Differential fror Arbitration Exempts Transmission fro Arbitration Exempts 4X4 fro
Front or Rear Differential	Head Gasket Leak Undetermined Engine Problem Other Engine Components Differential Noise cessive Play/ Slack in the Differential Front Differential Transmission Slipping Transmission Shudder Acceleration Shudder Delayed/ Harsh Engagement Transmission Inoperable Specific Gears 4X4 Not Engaging/ Disengaging HUB Locking Problem 4X4 & 4WD Warning Light O2 Sensor Codes	Turbo Leak Sludge Cam Phasers Differential Locking or Binding Differential Leak Rear Differential Abnormal/ Hard Shifting Transmission Leaks Transmission Whining Torque Converter Problem Reverse Not Engaging Not Functioning Transfer Case Overheating Binding In 4 x 4 Transfer Case Leaking	Yellow Light Required Transmission Problem Yellow Light Required 4X4 System Problem Yellow Light Required	Differential from Arbitration Exempts Transmission fro Arbitration Exempts 4X4 fro
Front or Rear Differential	Undetermined Engine Problem Other Engine Components Differential Noise cessive Play/ Slack in the Differential Front Differential Transmission Slipping Transmission Shudder Acceleration Shudder Delayed/ Harsh Engagement Transmission Inoperable Specific Gears 4X4 Not Engaging/ Disengaging HUB Locking Problem 4X4 & 4WD Warning Light O2 Sensor Codes	Sludge Cam Phasers Differential Locking or Binding Differential Leak Rear Differential Abnormal/ Hard Shifting Transmission Leaks Transmission Whining Torque Converter Problem Reverse Not Engaging Not Functioning Transfer Case Overheating Binding In 4 x 4 Transfer Case Leaking	Yellow Light Required Transmission Problem Yellow Light Required 4X4 System Problem Yellow Light Required	Differential from Arbitration Exempts Transmission fro Arbitration Exempts 4X4 fro
Front or Rear Differential	Other Engine Components Differential Noise cessive Play/ Slack in the Differential Front Differential Transmission Slipping Transmission Shudder Acceleration Shudder Delayed/ Harsh Engagement Transmission Inoperable Specific Gears 4X4 Not Engaging/ Disengaging HUB Locking Problem 4X4 & 4WD Warning Light O2 Sensor Codes	Cam Phasers Differential Locking or Binding Differential Leak Rear Differential Abnormal/ Hard Shifting Transmission Leaks Transmission Whining Torque Converter Problem Reverse Not Engaging Not Functioning Transfer Case Overheating Binding In 4 x 4 Transfer Case Leaking	Yellow Light Required Transmission Problem Yellow Light Required 4X4 System Problem Yellow Light Required	Differential from Arbitration Exempts Transmission fro Arbitration Exempts 4X4 fro
Transmission 4X4	Differential Noise cessive Play/ Slack in the Differential Front Differential Transmission Slipping Transmission Shudder Acceleration Shudder Delayed/ Harsh Engagement Transmission Inoperable Specific Gears 4X4 Not Engaging/ Disengaging HUB Locking Problem 4X4 & 4WD Warning Light O2 Sensor Codes	Differential Locking or Binding Differential Leak Rear Differential Abnormal/ Hard Shifting Transmission Leaks Transmission Whining Torque Converter Problem Reverse Not Engaging Not Functioning Transfer Case Overheating Binding In 4 x 4 Transfer Case Leaking	Yellow Light Required Transmission Problem Yellow Light Required 4X4 System Problem Yellow Light Required	Differential from Arbitration Exempts Transmission fro Arbitration Exempts 4X4 fro
Transmission 4X4	cessive Play/ Slack in the Differential Front Differential Transmission Slipping Transmission Shudder Acceleration Shudder Delayed/ Harsh Engagement Transmission Inoperable Specific Gears 4X4 Not Engaging/ Disengaging HUB Locking Problem 4X4 & 4WD Warning Light O2 Sensor Codes	Differential Leak Rear Differential Abnormal/ Hard Shifting Transmission Leaks Transmission Whining Torque Converter Problem Reverse Not Engaging Not Functioning Transfer Case Overheating Binding In 4 x 4 Transfer Case Leaking	Yellow Light Required Transmission Problem Yellow Light Required 4X4 System Problem Yellow Light Required	Differential from Arbitration Exempts Transmission from Arbitration Exempts 4X4 from
Transmission 4X4	Front Differential Transmission Slipping Transmission Shudder Acceleration Shudder Delayed/ Harsh Engagement Transmission Inoperable Specific Gears 4X4 Not Engaging/ Disengaging HUB Locking Problem 4X4 & 4WD Warning Light O2 Sensor Codes	Rear Differential Abnormal/ Hard Shifting Transmission Leaks Transmission Whining Torque Converter Problem Reverse Not Engaging Not Functioning Transfer Case Overheating Binding In 4 x 4 Transfer Case Leaking	Yellow Light Required Transmission Problem Yellow Light Required 4X4 System Problem Yellow Light Required	Differential from Arbitration Exempts Transmission fro Arbitration Exempts 4X4 fro
Transmission	Transmission Slipping Transmission Shudder Acceleration Shudder Delayed/ Harsh Engagement Transmission Inoperable Specific Gears 4X4 Not Engaging/ Disengaging HUB Locking Problem 4X4 & 4WD Warning Light O2 Sensor Codes	Abnormal/ Hard Shifting Transmission Leaks Transmission Whining Torque Converter Problem Reverse Not Engaging Not Functioning Transfer Case Overheating Binding In 4 x 4 Transfer Case Leaking	Transmission Problem Yellow Light Required 4X4 System Problem Yellow Light Required	Exempts Transmission fro Arbitration Exempts 4X4 fro
4X4	Transmission Shudder Acceleration Shudder Delayed/ Harsh Engagement Transmission Inoperable Specific Gears I 4X4 Not Engaging/ Disengaging HUB Locking Problem 4X4 & 4WD Warning Light O2 Sensor Codes	Transmission Leaks Transmission Whining Torque Converter Problem Reverse Not Engaging Not Functioning Transfer Case Overheating Binding In 4 x 4 Transfer Case Leaking	Yellow Light Required 4X4 System Problem Yellow Light Required	Transmission fro Arbitration Exempts 4X4 fro
4X4	Acceleration Shudder Delayed/ Harsh Engagement Transmission Inoperable Specific Gears 4X4 Not Engaging/ Disengaging HUB Locking Problem 4X4 & 4WD Warning Light O2 Sensor Codes	Transmission Whining Torque Converter Problem Reverse Not Engaging Not Functioning Transfer Case Overheating Binding In 4 x 4 Transfer Case Leaking	Yellow Light Required 4X4 System Problem Yellow Light Required	Transmission fro Arbitration Exempts 4X4 fro
4X4	Delayed/ Harsh Engagement Transmission Inoperable Specific Gears 4X4 Not Engaging/ Disengaging HUB Locking Problem 4X4 & 4WD Warning Light O2 Sensor Codes	Torque Converter Problem Reverse Not Engaging Not Functioning Transfer Case Overheating Binding In 4 x 4 Transfer Case Leaking	Yellow Light Required 4X4 System Problem Yellow Light Required	Transmission fro Arbitration Exempts 4X4 fro
4X4	Transmission Inoperable Specific Gears I 4X4 Not Engaging/ Disengaging HUB Locking Problem 4X4 & 4WD Warning Light O2 Sensor Codes	Reverse Not Engaging Not Functioning Transfer Case Overheating Binding In 4 x 4 Transfer Case Leaking	4X4 System Problem Yellow Light Required	Arbitration Exempts 4X4 fro
4X4	Specific Gears 4X4 Not Engaging/ Disengaging HUB Locking Problem 4X4 & 4WD Warning Light O2 Sensor Codes	Not Functioning Transfer Case Overheating Binding In 4 x 4 Transfer Case Leaking	Yellow Light Required	Exempts 4X4 fro
4X4	4X4 Not Engaging/ Disengaging HUB Locking Problem 4X4 & 4WD Warning Light O2 Sensor Codes	Transfer Case Overheating Binding In 4 x 4 Transfer Case Leaking	Yellow Light Required	
4X4	HUB Locking Problem 4X4 & 4WD Warning Light O2 Sensor Codes	Binding In 4 x 4 Transfer Case Leaking	Yellow Light Required	
	4X4 & 4WD Warning Light O2 Sensor Codes	Transfer Case Leaking	Yellow Light Required	
Emissions Afterm	O2 Sensor Codes	, in the second s		Albitration
Emissions Aftermatic		Failed/Inoperable Catalytic Converter		
Emissions Afterma			Emissions Problem Yellow Light Required Emissions Modified Yellow Light Required Emissions Missing Yellow Light Required	Exempts Emissions from Arbitration
Emissions Afterma	Catalyst System Codes	Faulty or Damaged Mass Airflow Sensor		
	narket Modifications Affecting Emissions	Performance Tuned Emissions Components		
	Deleted Emissions Equipment	Missing Catalytic Converter		
	Adaptive Cruise Control Defect	Front and/ or Rear Camera Problem	ADAS Problem	Exempts ADAS Systems from Arbitration
	Collision Avoidance Malfunction	ADAS System Warning Lights		
ADAS A	Automatic Braking Systems Failure	Backup or Parking Assist Malfunction	Yellow Light Required	
	Blind Spot Detection Issue	Lane Departure Defect	•	
	Collision Damage A	ADAS Components		
Hechanical	High Performance Super Chargers	Engine Tuners	Aftermarket Alterations/ Modifications (by component)	Exempts Alterations and Modifications from Arbitration
	rmance Tuned Emissions Components	Racing Camshafts		
Afte	ermarket Turbocharger/Supercharger	Missing Components	Yellow Light Required	
	Battery Pack Failure	Battery Pack Charge to 50% or Less	As Is	Exempts EV or Hybrid Battery from Arbitration
Electric or	Inverter Failure	Electric Motor	Red Light Recommended EV/Hybrid Battery Problem Yellow Light Required	
	Regenerative Braking Motor Issues	EV Motor Cooling System Failure		
	Hybrid or Electri			
	Kinked A,B and C Pillars	Structural Tear Damage greater than 1"	3 1 1	
		Excessive Rust and Corrosion that	Structural Damage Yellow Light Required	Exempts Structural Damag from Arbitration
	Kinked Frame Rails and Aprons	compromises Structural Components		
Damage	Cross Member Cut or Damaged	Drilled Holes Larger than 5/8		
	Structural/ Fra	Ţ		
	Policy I	Reminders: Restrictive Announcements	• •	-